

Attaching a Device to and Electrical Box

Facility:	Written By:	Approved By:	Date Created:	Date of Last Revision

Hazards Present:	PPE or Devices Required:	Additional Training Required:
Pinching	Eye protection	
	Gloves	

Safe Work Procedure:

1. Grab the stripped wire and a use a pair of needle nose pliers to make a loop in the wire
2. Place the loop around the appropriate screw in a clockwise direction and tighten up the screw
3. Repeat as necessary
4. Attach the device to the box

If an emergency situation occurs while conducting this task, or there is an equipment malfunction, engage the emergency stop and follow the lock out procedure

REPORT ANY HAZARDOUS SITUATIONS TO YOUR SUPERVISOR

Guidance Documents/Standards: MB Workplace Safety & Health Act & Regulations:	This Safe Work Procedure will be reviewed any time the task, equipment or materials change and at a minimum of every three years
	Reviewed By WSH Committee: Date: