

Getting Loaded (Cement)

Facility:	Written By:	Approved By:	Date Created:	Date of Last Revision

<b>Hazards Present:</b>	<b>PPE or Devices Required:</b>	<b>Additional Training Required:</b>
Trips		
Slips		

**Safe Work Procedure:**

- 1) Back up under the sock, ensuring that the sock drops fully into the hopper of the mixer
- 2) Rev up the mixer ensuring that the drum is turning in the charge position at max revolutions
- 3) Exit the mixer and grab the hose to fill your side water tank
- 4) Turn the valve on “plant” to fill your side tank with water, ensuring that you don’t let the water spill over once its full
- 5) Remove the hose and enter the plant
- 6) Get your load ticket from the dispatcher
- 7) Ensure you know where the job is and the route you have to take before leaving the plant
- 8) Once the bather is done follow him to the back of your mixer and discharge the drum until he signals to stop so that he can check the concrete.
- 9) Once the batcher has given you the go-ahead, enter your mixer and proceed to the jobsite

***If an emergency situation occurs while conducting this task, or there is an equipment malfunction, engage the emergency stop and follow the lock out procedure***

**REPORT ANY HAZARDOUS SITUATIONS TO YOUR SUPERVISOR**

<b>Guidance Documents/Standards:</b>  MB Workplace Safety & Health Act & Regulations	This Safe Work Procedure will be reviewed any time the task, equipment or materials change and at a minimum of every three years
	Reviewed By WSH Committee:  Date: